






- Rotation sensitive
- Glass interface(white & black)
- Compatible with all universal series RF receivers

- Control 1 zone/area

Picture		Brief introduction of buttons	
			
Click the knob to switch ON/OFF. Rotate the knob to dim between 1% to 100%.			
Operation Voltage	Operation Frequency	Note : This remote controls 1 zone (area) receivers, the zone can pair with countless receivers. 1 receiver can be paired by max 8 different remote controls.	
3V(CR2032)	868MHz		
Size			
			
			

Installation	
	
Operation	
Note:Before the first use, please remove the protective film on the battery.	
1. Pair with RF receivers: Click "Learning Key" on RF receiver → Rotate or click the knob, led lights flicker twice means well paired	
2. How to delete the pairing: Power on the RF receiver, hold the "Learning Key" over 3 seconds until connected led lights flicker twice means well deleted.	